



CHANGING THE JUG IN BOX (JIB)

1. Display shows “JIB IS LOW” and yellow light comes on, replace the JIB.
2. Open right door and slide JIB from shelf. Pull the cap from top and pour any remaining oil into the vats equally.
3. Prepare new jug to accept the tube and insert tube into new jug. Then slide new jug into position under fryer.



FILLING THE JUG IN BOX (JIB) ON BULK SYSTEM FRYERS (RTI)

1. Display shows “JIB IS LOW” and yellow light comes on, replace the JIB.
2. Open the door, that has the RTI switch.
3. Press & hold the ADD side of the RTI switch to add oil to the JIB




Any problems, refer to manual or contact Henny Penny Corp. 1-800-417-8405, or 937-456-8405.

NOTICE

These instructions are meant to be guidelines, not complete operating instructions. Read and understand the complete operator's manual supplied with each unit.



MUDANÇA DA EMBALAGEM DE ÓLEO (*JUG IN BOX - JIB*)

1. O visor apresenta a mensagem “JIB IS LOW” (NÍVEL DE ÓLEO BAIXO NO JIB) e a luz amarela acende; a embalagem de óleo (JIB) deve ser substituída.
2. Abrir a porta do lado direito e remover a embalagem (JIB) do óleo da prateleira da fritadeira. Remover a tampa do topo e despejar quaisquer restos de óleo igualmente nas cubas da fritadeira.
3. Preparar a nova embalagem de óleo de modo a aceitar o tubo de aspiração; introduzir o tubo na nova embalagem de óleo. Depois, colocar a nova embalagem de óleo sob a fritadeira.



ENCHIMENTO DA EMBALAGEM DE ÓLEO BOX (JIB) EM FRITADEIRAS COM SISTEMA DE ARMAZENAMENTO DE ÓLEO A GRANEL (RTI)

1. O visor apresenta a mensagem “JIB IS LOW” (NÍVEL DE ÓLEO BAIXO NO JIB) e a luz amarela acende; a embalagem de óleo (JIB) deve ser substituída.
2. Abrir a porta com o interruptor do sistema RTI.
3. Manter premido o lado ADD (ADICIONAR ÓLEO) do interruptor do sistema RTI, para adicionar óleo à embalagem (JIB) de óleo.



Para dúvidas e problemas, consultar o manual ou contactar a Henny Penny Corp. através do telefone +1-937-456-8405.

NOTICE

NOTA

Estas instruções devem ser consideradas como linhas de orientação gerais e não como instruções de operação completas. Ler e compreender na totalidade o manual de operação fornecido com o equipamento.